

## E-515

# Display Modules

### Ordering Information

E-515.01  
Display Module for PZT  
Voltage/Displacement

E-515.03  
Display Module for PZT  
Voltage/Displacement, 3 Channels

Custom Designs  
for Volume Buyers

- 3½-digit LED Display
- For Voltage & Displacement Data
- 1 & 3 Channel Versions

The E-515.01 and E-515.03 are one and three channel display modules for PZT voltage and displacement data. Toggle switches for each channel select voltage or displacement mode. The voltage/displacement range for each channel is internally set by jumpers and trimmers.



E-515.03

### Notes

E-515 is not a stand-alone device. It is designed to work in the E-500/E-501 chassis (p. 6-20), the E-471 or the E-480 amplifier (p. 6-24, 6-26) with integrated power supply.

### Technical Data

Models	E-515.01	E-515.03
Function	Display for voltage & displacement	Display for voltage & displacement
Channels	1	3
Linearity	0.1%	0.1%
Display	1 x 3½-digits	3 x 3½-digits
Dimensions	One 21T slot wide, 3H high	One 21T slot wide, 3H high
Weight	0.3 kg	0.3 kg
Operating voltage	Requires E-530/E-531 power supply (E-500/E-501 system, etc.)	Requires E-530/E-531 power supply (E-500/E-501 system, etc.)